



**Q: How do I use Maxim DL with my FLI camera?**

**A: To use Maxim with our cameras you must:**

1. Shut down Maxim DL
2. Go to <http://www.flicamera.com/fli/software.asp> on the web and choose the FLI Software Installation Kit link. This will download a file named FLISetup.msi.
3. Run the FLI Setup installer (The FLI Software Installation Kit installs FLI's applications, USB device drivers, and ASCOM driver for the focuser products). You will need to remove any previous FLI software before installing this package.
4. Go to <http://www.flicamera.com/software/index.html> on the web and choose the FLI Maxim DL/CCD Plug-In link. This will download a zipped file named CCDPlugFingerLakes.zip.
5. Unzip these files into the Maxim DL/CCD directory for the latest Plug-In with support for speed changing and RBI elimination.
6. After restarting Maxim DL you should see the proper FLI camera listed.