



Q: How do I use Maxim DL with my FLI camera?

A: To use Maxim with our cameras you must:

1. Shut down Maxim DL
2. Navigate to <http://www.flicamera.com/software/index.html>
3. Download and install the FLI Software Installation Kit.
4. Run the FLI Setup installer (The FLI Software Installation Kit installs FLI's applications, USB device drivers, and ASCOM driver for the focuser products). You will need to remove any previous FLI software before installing this package.
5. Download and install the FLI MaxIM DL/CCD Plug-In. This will download a zipped file named CCDPlugFingerLakes.zip.
6. Unzip these files into the MaxIM DL/CCD directory for the latest Plug-In with support for speed changing and RBI elimination.
7. After restarting MaxIM DL you should see the proper FLI camera listed.